



Correct mounting of steering damper so as to prevent hard impacts and bending of bracket on frame during extreme steering positions.

A- Extend the steering damper from sleeve by 20mm

B- Use 3 aluminum washers with part Number [051651](#)

C- Correct set up of steering stopper with respect to the lower frame tube

D- Ensure the ball joint functions correctly in the sleeve with 2 washers [051420](#) on both sides of the ball joint. After assembling verify that sleeve can tilt